# Layout Generation

Carsten Wulff, carsten@wulff.no

# I. LAYOUT

The open source tools don't have any automatic analog layout. To my knowledge, there is no general purpose analog automagic layout anywhere in the world. It's an unsovled problem. Many have tried (including myself), but none have succeeded with a generic analog layout engine.

There are a few things, though, that could help you on the way.

### II. SETUP

I assume that you have the latest and greatest aicex\ip setup.

#### See SKY130NM Tutorial if aicex is unfamiliar.

Let's assume we use jnw\_gr05\_sky130a to test out our layout

```
cd aicex/ip/
cd jnw_gr05_sky130a
git checkout ale3dfc324194729e042f5e653777b052759863b
cd work
```

## III. CICPY

The first thing we need to do is to place all transistors. I do have a script to help. Install cicpy.

cd aicex/ip/cicpy
git checkout master
git pull
python3 -m pip install -e .
cd ..
cd cicspi
git checkout main
git pull
python3 -m pip install -e .


#### IV. PLACEMENT

To generate an initial placement we can do the command below. If a layout exists it will be overriden

cd jnw\_gr05\_sky130a/work cicpy sch2mag JNW\_GR05\_SKY130A OTA\_Manuel



The layout engine has no idea what components belong together, for example, the current mirror below should have been place together




We can instruct the layout engine by adding a "group" name to the instance name. The instance name always starts with x < something > (number) where the something can be nothing, or a group name (a,b, not a number).

The rules for placement are:

- 1. Sort all instances by groups
- 2. Sort all groups by instance name
- 3. Place the first instance.
- 4. For all instances: If the next instance has the same group, then add on top. Otherwise increment the x location.

As such, if I rename my instances, as shown below,




Then the layout becomes a bit better


cicpy sch2mag JNW\_GR05\_SKY130A OTA\_Manuel --gbreak 3 --xspace 34000 --

The gbreak command inserts a "group break" after the fourth group, such that a new Y coordinate is selected.

The X and Y space is for the distance between groups. The unit is "Ångstrøm", so 1 um is 10 000 Å.

r Layers Drc Options Devices 1 Devices 2 DRC=0 Loaded: OTA\_Manuel Editing: OTA\_Manuel Tool: box Ter





I Layers Drc Options Devices 1 Devices 2 DRC=0 Loaded: OTA\_Manuel Editing: OTA\_Manuel Tool: box Technology: sky



**Carsten Wulff** received the M.Sc. and Ph.D. degrees in electrical engineering from the Department of Electronics and Telecommunication, Norwegian University of Science and Technology (NTNU), in 2002 and 2008, respectively. During his Ph.D. work at NTNU, he worked on open-loop sigma-

delta modulators and analog-to-digital converters in nanoscale CMOS technologies. In 2006-2007, he was a Visiting Researcher with the Department of Electrical and Computer Engineering, University of Toronto, Toronto, ON, Canada. Since 2008 he's been with Nordic Semiconductor in various roles, from analog designer, to Wireless Group Manager, to currently Principle IC Scientist. He's also an Adjunct Associate Professor at NTNU. His present research interests includes analog and mixed-signal CMOS design, design of highefficiency analog-to-digital converters and low-power wireless transceivers. He is the developer of Custom IC Compiler, a general purpose integrated circuit compiler.